Software

Once CM4 is connected, up and running you can use different software and protocols to stream your music. For handheld Android devices we recommend using BubbleUPNP or BubbleDS app. For handheld IOS devices we recommend using mconnect Player Lite, mconnect Player or mconnect HD.

Simply follow the below steps to get started

1. Download and install one of the following the apps:

App Store (IOS)

mconnect Player Lite (free)
mconnect Player
mconnect HD

Google Play (Android)

BubbleUPNP (free)
BubbleUPNP License
BubbleDS

2. Make sure your handheld device is connected to the same network as your Streamer.

3. Follow one of our app guides on the following pages to get started with your handheld device.

mconnect Player

Instructions to get started with mconnect Player IOS app

1. Start the app

2. Click "Play to"

3. Select G-Dis

4. Click "Player" and check the volume level is not too loud


5. Click on the "Gear" icon



6. Choose "Cloud Setup"

7. Make sure the services you want to use are active. Eg Qobuz/Tidal and return


8. Click "Browse"

9. Choose your preferred streaming service and sign in with your credentials


10. Click the menu icon


11. To search for music click "Search"

12. Write search criteria. Eg artist, album or title and click "Search"

13. Choose how to filter your result by Artis, Album, Tracks or Playlists

14. Choose one of the results to play

15. During play you can pause, skip, back, stop, change volume, etc.

16. Tip! Click on volume icon to change sensitivity of the volume slider

BubbleUPNP

Instructions to get started with BubbleUPNP Android app

1. Start the app

2. Click on the devices icon

3.Select G-Dis


4. Click "More"

5. Choose your preferred streaming service and sign in with you credentials


6. Use the physical volume buttons and check the volume level is not too loud


7. Click on the search icon

8. Write search criteria. Eg artist, album or title and click the search icon

9. Choose how to filter the results by Albums or Tracks and choose a result

10. During play you can pause, skip, back, stop, change volume, etc.